

# Hybrid Flooring INSTALLATION GUIDE

## 2G ANGLE TO ANGLE

### PRODUCTS: SIENA

Materials shall be installed in accordance with AUSTRALIAN STANDARDS 1884: 2012 Floor Coverings – Resilient Sheet and Tiles – Installation Practices.

Please read and follow all instructions below before installation. Please ensure that a dust mask (minimum P2) is used during installation.

### INTRODUCTION:

Hybrid Plank is a floating floor product system that can be installed over nearly any indoor existing floor structure. A 10mm expansion gap around the perimeter is required as the product may expand and contract with heat and humidity. As the product is designed to expand and contract, and cannot be locked down at the edges of the room with scotia or skirting board; a 1mm gap must be left between scotia/skirting board and floor. NFD supply matching trims and scotia to cover expansion gaps where required, otherwise a moulding system is required to cover the gap when skirtings are left in place. An expansion gap is required over any area greater than 15m in length or width.

#### DO NOT:

- At any point, attach hybrid plank to subfloor
- Fit flush against fixed vertical surfaces

Hybrid Planks are not designed to act as a moisture barrier and is not to be installed in potential flooding or standing water areas. In the case of standing water or flooding, any damage caused is not covered by this warranty.

Hybrid Planks are not to be used as a thermal barrier and sub floor insulation must be used if the below void is open to the natural environment. Approved ventilation is also critical in the below void area.

### PRE-INSTALLATION CHECKLIST:

The installer is responsible to check all flooring material prior to installing. Use the following checklist:

- Is this the correct product (colour, pattern, dimensions)?
- Are the client's expectations met with the product?
- Is the installation guide and recommendations being followed?
- Has the product been kept in the same environment for at least 24 hours?

#### **Installer Responsibility:**

- Prior to installing, flooring should be inspected and the installer must determine that the job-site environment and associated subfloor meet or exceed all applicable standards. NFD declines any job failure responsibility resulting from or associated with subfloors, substrates or job-site environmental deficiencies. Construction and material industries

recommendations, as well as local statutory codes, must be adhered. It is recommended that the construction and subfloor be flat, dry and structurally sound. Stain, filler or putty stuck for touch-up and other appropriate products for correcting subfloor voids is acceptable, as part of normal installation procedures.

## SUBFLOORS:

- The subfloor condition can influence the finished appearance and dramatically affect the life and serviceability of the floor. All floors must be smooth, clean and dry before installation
- Hybrid Flooring can be installed over most existing hard floor covering surfaces, see below for notes and requirements for surfaces. Carpet and other soft flooring products are not suitable substrates.

### **Subfloor preparation must adhere to Australian Standards 1844: 2012 Resilient Sheet and Tiles Installation Practices.**

- **Planeness:** Ensure that the floor surface is smooth and level; when a straight edge 2000mm long is placed at any position at rest at two points on the surface, no part of the surface shall be more than 4mm below the straightedge. Any high points should be removed to become consistent with the level.
- **Smoothness:** When a straightedge 150mm long is placed at any position at rest at two points on the surface, no part of the surface shall be more than 1mm below the straightedge.
- **Concrete Subfloors:** Concrete subfloors must be below 5.5% moisture content.
- **Timber Subfloors:** Timber floors must be structurally sound and within the planeness tolerance stated above.

### **A record of a moisture test results must always be carried out in accordance with Australian Standards 1884: 2012 Appendix A.**

Hybrid Planks are not designed as a moisture barrier, damp proof membrane or waterproofing barrier, and is not to be installed in potential flooding or standing water areas. In the case of standing water or flooding, any damage caused is not covered by this warranty.

**Heating Systems:** Follow the instructions below to install Hybrid Planks over radiant heating systems.

1. The radiant heat surface temperature must not exceed 28°C
2. Use the radiant heating system at maximum capacity to remove any excess moisture, before installing.
3. Maintain the room temperature between 15-26°C before installation.
4. Flooring products must be kept in the same environment for at least 24 hours before use.
5. Apply radiant heat gradually, 24 hours after installation

## INSTALLATION:

1. Prepare all rulers, cutters, spreaders and compass dividers before begin to work.
2. Check that the colour is as selected. Once installed NFD is not responsible for colour/dye or colour inconsistencies. Check that the boxes of planks are of the same batch/lot number.
3. Find the exact centre of the floor by marking vertical and horizontal lines across the floor.
4. Measure the squareness of the marked lines, and then start on the first quarter of the marked floor space.
5. Keep a distance of 10mm from the wall and the edge of the flooring products. Press products down firmly so that the products lie flat on the ground.

## CUSTOM STAIR TREAD:

Stairs must be clean dry and free from any debris suitable for bonding to. Stairs need to be square edge and therefore the face may need to be packed.

Remove any cushion underlay backing from all product that is to be used on the stairs.

Custom stair treads must be fully adhered to the tread and face of the stair by using the timber insert. All products used on stairs must also be fully adhered. A suitable high temperature resistant adhesive must be used.

The top custom stair tread must also be fixed to the stair and if the same product is used adjoining an expansion must be left with a T cover or any other suitable cover allowing for the correct expansion space.